

WORLD HEADQUARTERS 3879 North Richards Street ■ Milwaukee, WI 53212

TOLL-FREE 800-932-0685 ■ PHONE 414-964-3668 ■ FAX 414-964-5767

E-MAIL orders@fatsac.com or orders@barefootinternational.com ■ WEB www.barefootinternational.com

TYPE OF BOOM

1 B200 — DELUXE STRAIGHT BOOM

Windshield is in front of pylon and pylon is **NOT** tapered.

2 B201 — DELUXE SINGLE / STRAIGHT CONTOUR BOOM

Windshield is in front of pylon and pylon is tapered.

3 202 — DELUXE UNIVERSAL CONTOUR BOOM

Windshield is even or up to 8 inches behind pylon.

4 B204 — DELUXE QUAD CONTOUR BOOM

Windshield is more than 8 inches behind pylon.

5 B204-V — DELUXE QUAD V-DRIVE BOOM

V-Drive boats with rear pylons. Make sure that the pylon is **NOT** tapered at least 3 inches at the bottom or call the boat factory to get a replacement pylon that has at least 3 inches that is **NOT** tapered at the bottom for Boom clamps to hold safely.

6 B205 — GUNNEL BOOM

For boats **WITHOUT** factory installed pylons.

7 B202-XTI — MALIBU XTI BOOM

This is for the new XTI Malibus with retractable pylons.

WARNING:

With all booms, the boom clamps must be attached below the taper on the pylon.